




1800      5561      5486      5561

1024  
11788  
7000

CORNER UNIT      INTERMEDIATE UNIT      END UNIT

GROUND FLOOR PLAN  
DOUBLE STOREY TERRACE



CORNER UNIT                      INTERMEDIATE UNIT                      END UNIT

1ST FLOOR PLAN  
DOUBLE STOREY TERRACE